

FRONT

6047-MUG-R0
15-0604704-P3-0A02**DISC REPAIR KIT****1-YEAR LIMITED WARRANTY**

Mad Catz warrants this product to be free from defects in materials and workmanship for the warranty period. This non-transferable, one (1) year limited warranty is only to you, the first end-user purchaser. If a defect covered by this warranty occurs AND you have registered your product with Mad Catz AND you provide proof of purchase, Mad Catz, at its option, will repair or replace the product at no charge.

The Mad Catz one (1) year limited warranty is available to North American and Australian customers only, including Canada, Mexico and the United States. Your sole and exclusive remedy is repair or replacement of your Mad Catz product. In no event shall Mad Catz liability exceed the original purchase price of the product. This warranty does not apply to: (a) normal wear and tear or abusive use; (b) industrial, professional or commercial use; (c) if the product has been tampered with or modified.

To receive warranty service you must:

- Call Mad Catz Technical Support at 1.800.659.2287 or 1.619.683.2815
- Obtain a Return Authorization Number from Mad Catz Technical Support
- Ship the product to Mad Catz at your expense for service
- Enclose a copy of the original sales receipt showing a purchase date
- Enclose a full return address with daytime and evening phone numbers

TECHNICAL SUPPORT

Online Support and User Guides: www.madcatz.com

E-mail: techsupport@madcatz.com

Telephone: Available 8 A.M. to 4 P.M. Pacific Standard Time, Monday through Friday (excluding holidays) at 1.800.659.2287 (US only) or 1.619.683.2815 (outside US).

DISC REPAIR KIT

The Disc Repair Kit is designed to save you money.

Features:

- Motorized CD/DVD Repair Unit
- Repairs skipping, scrambling and disc loading problems
- Removes scratches from game CDs, DVDs and CDs
- Also works with mini-disc

Finally you can remove the scratches and blemishes on all your CDs and make them work like new with the simple push of a button. So gather all of your damaged Video Game CDs, DVDs and Music CDs and prepare to start enjoying them all over again.

Minor Damaged Disc Repair Instructions:

1. Plug in your repair unit. Open the top cover by pressing the open button. (fig.1)
2. If your CD has a light scratch or scratches simply place 1-2 small drops of repair solution onto the yellow head marked wet (right side). (fig.2)
3. Insert your damaged disc data side down. Press the start button. (fig. 3) The CD is repaired when the unit stops (lasts for 3 minutes approximately)

Major Damaged Disc Repair Instructions:

If your CD still is experiencing problems or you are trying to repair a CD with deep scratches,

1. Remove the yellow repair heads by turning the repair head counter-clockwise.
2. Replace the yellow repair heads with included pink buffer heads.
3. Press the start button. The unit will stop automatically after 3 minutes approximately.
4. Replace back the yellow repair head with added 1-2 small drops of repair solution
5. Press the start button. The CD is repaired when the unit stops.

Note: If you're still experiencing problems after trying both the 'repair' or 'buffer' methods, you may need to repeat the pink buffer method up to a maximum of 3 times (and followed with yellow repair method), to ensure all scratches have been removed.

Rest the units for 30 minutes after repaired 5 discs continuously.

After using the yellow repair heads 5 times, dry them out completely before next use.

WARNING: This product contains Aluminum Hydroxide.

CAUTIONS

- This product should not be used without adult supervision.
- Keep out of reach of children.
- Extremely flammable, keep away from open flame.
- Do not eat. If eaten, do not induce vomiting. Drink 2-4 cups of milk or water. If adverse symptoms appear, consult a physician.
- Avoid contact with eyes. If cleaner gets in eyes, flush with water for at least 15 minutes, occasionally lifting the upper and lower eyelid. If irritation continues, seek medical attention.
- Wash hands after every use. If skin irritation occurs wash area thoroughly with soap and water for up to 15 minutes.
- Use this unit only as intended.
- To prevent fire or shock hazard, do not expose this unit to rain or moisture. Do not use within 30' of any water such as swimming pools, bathtubs, or sinks.
- To avoid electrical shock, do not disassemble. Refer servicing to qualified personnel only.
- This unit should be operated only from the power source indicated on the unit. If you are not sure of the type of electrical power supplied to your home, contact your local power company.
- Never push objects of any kind, other than authorized items, into the product as they may touch dangerous voltage points or short out parts that could result in fire or electrical shock.
- Do not attempt to operate the unit in any way except with your hands. Do not bring the unit in contact with your head, face, or near the bones of any other part of your body.
- Route all cords so that they are not likely to be walked on or tripped over. Make sure that cords are not placed in positions or areas where they may become pinched or damaged. Do not wrap this cord around any part of

SIZE: 66 X 223MM

BACK

6047-MUG-R0
15-0604704-P3-0A02

anyone's body.

- Do not allow children to play with cords.
- Do not overload wall outlets or extension cords beyond their capacity, since doing so can cause fire or electric shock.

Thank you for purchasing the Mad Catz Disc Repair Kit for use with Compact Discs or DVDs. Be sure to register your product online at www.madcatz.com and check out our full line of other quality video game accessories.

©2004 Mad Catz, Inc. 7480 Mission Valley Rd., Suite 101, San Diego, CA 92108. Mad Catz and the Mad Catz logo are trademarks or registered trademarks of Mad Catz, Inc., its subsidiaries and affiliates. The shape and design of this product is a trademark of Mad Catz. International and domestic patents pending. Made in China. Printed in Hong Kong. All rights reserved. Features, appearance and specifications may be subject to change without notice. Mad Catz stands behind its products 100%.

Questions? Visit our web site at www.madcatz.com or call 1.800.659.2287 (USA only) or 1.619.683.2815.

Product No. 6047 06/04
P30-6047




fig. 1




fig. 2




fig. 3

SIZE: 66 X 223MM